



1. Seal tape, to head and jambs by window installer
2. Apply two coats of Matflex to all blockwork from inner air seal to outer edge of reveal all around all above ground penetrations
3. Window installer to apply seal tape to back of frame and push window into rebate
4. Foam airseal by builder
5. Window installer to apply a 10mm bead of MS sealant to head and jambs. Plasterer to apply 6mm bead of MS sealant between plaster and masked joinery
6. Masonryplast
7. If a drip edge moulding is not used, plaster in a drip edge
8. Mask joinery to avoid plaster damage
At sill leave a 5mm drainage gap

I CONCRETE BLOCK ALUM. HEAD / JAMB AND SILL